

## **NOTICE TO TANK TRUCK DRIVERS**

### Tank Truck Drivers

To prevent the release of substances hazardous to the environment, tank truck drivers entering this site are to comply with the following rules:

1. Exercise caution when maneuvering to avoid damage to containment walls.
2. Inspect tank, fitting, and liquid level indicator prior to filling.
3. Place drip pans under all pump hose fittings prior to loading/unloading.
4. Block truck wheels before starting to load/unload.
5. Remain with the vehicle while loading/unloading.
6. Drain loading/unloading line to storage tank when loading/unloading is complete.
7. Verify that all drain valves are closed before disconnecting loading/unloading lines.
8. Inspect vehicle before departure to be sure all loading/unloading lines have been disconnected and vent valves closed.
9. Immediately report any leakage or spillage to the Central Monitoring Station, x1234, or onsite NREL personnel.