

The Effects of Light-Induced Degradation on the Electronic Properties of Hydrogenated Nanocrystalline Silicon

Adam F. Halverson, James J. Gutierrez, and J. David Cohen

Department of Physics, University of Oregon, Eugene OR 97401

with

Baojie Yan, Jeffery C. Yang, and Subhendu Guha

United Solar Ovonic Corp., Troy, MI 48084

Supported by: NREL Subcontract ADJ-2-30630-17

OUTLINE


- **Types of Nanocrystalline Silicon Samples Studied**
- **Drive Level Capacitance Profiling**
Effects of hydrogen profiling and Light Soaking
- **Transient Photocapacitance and Photocurrent Spectroscopy**
Temperature variation shows degree of minority carrier collection
- **Light-induced Degradation**
Reduces the minority carrier collection
- **Conclusions**



Types of Nanocrystalline Si Devices Studied

PIN

SS/n+/i/p+/TCO



Deposited at : United Solar Ovonic Corp.

Advantages:


- Purely nc-Si:H

Disadvantages:

- Has thin heavily doped p and n layers

SANDWICH

SS/n+/a-Si:H/nc-Si:H/a-Si:H



Advantages:

- Purely intrinsic
- Blocks diffusion of O₂

Disadvantages:

- Contains a-Si:H layers



We made measurements on both device types to isolate the spectral features due to the intrinsic nc-Si:H layer itself



Results from Drive-Level Capacitance Profiling





DLCP for nc-Si:H Films Deposit under Constant H-Dilution



- Response suggest responding states are *shallow donor-like states*
These states appear to lie within about 0.55eV of the conduction band edge
- The p-i-n device shows a similar spatial distribution of states that increase in the direction of the growing film
Grains become larger as the films become thicker hence more defective
- These films were deposited **without** hydrogen profiling





DLCP Results for Constant Hydrogen vs. Profiled Hydrogen



- For one sandwich sample the **hydrogen dilution was varied** to control the evolution of crystalline volume fraction and crystallite size
- The profiled sample exhibits a DLCP profile that reaches a maximum within the middle of the film but then decreases again
- Hydrogen profiling is also found to lead to an increase of nc-Si:H solar cell efficiency



Effects of Light Soaking on Defects Observed using DLCP



- Apart from slight horizontal shifts, **light soaking does not** appear to affect these drive-level profiles.




Transient Photocapacitance and Transient Photocurrent Spectroscopy




Comparing CPM and Photocapacitance Spectrum for nc-Si:H

Fourier-Transform Photo Current Spectroscopy (FTPS) and CPM Spectra



Very temperature dependent!



At higher temperatures spectra resemble those of a-Si:H




Hole Collection Inhibited in a-Si:H Component

At photon energies greater than 1.1eV, free electrons and holes excited in nanocrystallites.


At moderately high temperatures both carriers escape
⇒ little change in charge
⇒ small photocapacitance signal

In a-Si:H component many holes remain trapped
⇒ mostly electrons escape
⇒ large photocapacitance signal




Minority Carrier Collection Increases with T

Transient Photocapacitance



Increased minority carrier collection suppresses signal in nc-Si:H component

Transient Junction Photocurrent




Photocurrent signal dominated by nc-Si:H component at all T




a-Si:H Component Seen in all Samples

Sandwich Sample (H-profiled)



pin Sample




Indicates a-Si:H is present in nanocrystalline silicon as an integral component




Minority Carrier Collection is Activated

- When the nc-Si:H component of the spectrum is small, minority hole collection is large
- We examined the detailed temperature dependence in the region shown




Hole Collection in Crystalline Component is Thermally Activated



Light-Induced Degradation in nc-Si:H is Associated with a Reduction in Minority Carrier Collection





Hole Collection is Reduced at Lower Temperatures



By reducing the temperature from 240K to 180K, hole collection in the nanocrystalline component of this sample is reduced by at least a factor of 50.




A Similar Reduction Occurs after Light-Soaking!



Light-soaked State B at 240K displays a similar reduction in hole collection



Hole Collection Also Thermally Activated in State B




- ❖ Similar activation energies are exhibited in both the degraded and annealed states.
- ❖ Hole collection reduced after light soaking by roughly a factor of 20 at nearly all temperatures
- ❖ Suggests same hole traps are responsible in both cases, but that there are *more of them in State B*




Is an Increase in Deep Defects Responsible?

NO – Negligible changes in
180K sub-bandgap spectra for
series of metastable states



Series of anneals
at increasing
temperatures
from State B
back to State A

At higher temperatures one sees the
differences related to hole collection
Deep defect region still unchanged



Conclusions

- States observed using DLCP appear to be shallow and donor-like and their profile does not change significantly with light soaking
 - Their distribution and density can be modified by hydrogen profiling
- High quality optical spectra for nc-Si:H were obtained using transient photocapacitance spectroscopy
 - Can separate the nc-Si:H component from the a-Si:H component by changing the measurement temperature
 - Can determine an activation energy for minority carrier collection
- Light soaking leads to a degradation in minority carrier collection
 - Our results are correlate with the observed degradation of electrical properties in nc-Si:H solar cells found after light exposure
 - This degradation does not appear to involve an increase in the dangling bond density that can be observed in our sub-bandgap spectra

