

Control of Ionomer Distribution in Roll-to-Roll Coated Fuel Cell Catalyst Layers

Scott Mauger

September 18, 2018

NREL/PR-5900-72416

19th International Coating Science and Technology Symposium

Acknowledgements

NREL

- Mike Ulsh
- KC Neyerlin
- Sunilkumar Khandavalli

Carnegie Mellon University

- Leiming Hu
- Shawn Litster

Argonne National Laboratory

- Firat C. Cetinbas
- Rajesh Ahluwalia
- Jae Hyung Park
- Debbie Myers

DOE Adv. Manufacturing Office


- David Hardy




This work was authored in part by Alliance for Sustainable Energy, LLC, the manager and operator of the National Renewable Energy Laboratory for the U.S. Department of Energy (DOE) under Contract No. DE-AC36-08GO28308. Funding provided by U.S. Department of Energy Office of Energy Efficiency and Renewable Energy, Advanced Manufacturing Office, Program Manager David Hardy. The submitted manuscript was created, in part, by UChicago Argonne, LLC, Operator of Argonne National Laboratory, Argonne, U.S. Department of Energy Office of Science laboratory, is operated under Contract No. DE-AC02-06CH11357. This research used the resources of the Advanced Photon Source (APS), a U.S. Department of Energy (DOE) Office of Science User Facility operated for the DOE Office of Science by Argonne National Laboratory, also under Contract No. DE-AC02-06CH11357. The views expressed in the article do not necessarily represent the views of the DOE or the U.S. Government. The U.S. Government retains and the publisher, by accepting the article for publication, acknowledges that the U.S. Government retains a nonexclusive, paid-up, irrevocable, worldwide license to publish or reproduce the published form of this work, or allow others to do so, for U.S. Government purposes.

Proton Exchange Membrane Fuel Cells

- High efficiency (>2x internal combustion)
- Zero GHG emissions
- Long-range EV (300+ miles/tank)
- Short refueling time (5 min)




Fuel Cell Catalyst Layers




Fuel Cell Construction

Catalyst-Coated Membrane (CCM)





Catalyst Coated Diffusion Media (CCDM)



- Electrode applied to membrane
- Extensively used in laboratory experiments
- Challenging for manufacturing due to swelling of membrane

- Electrode applied to microporous layer
- Potentially simpler for manufacturing
- Some reports of improved fuel cell performance

CCDM Challenge




Can we control the distribution of ionomer to create a catalyst layer with an ionomer rich surface from a single coating step?

How can we control ionomer distribution?


- Ink Formulation
 - Water to 1-propanol ratio
 - 25 and 75 wt% water
 - Ionomer-to-Carbon ratio (I:C)
 - 0.9
 - 1.2
 - 1.6
- Drying Temperature
 - 25 °C
 - 60 °C
 - 80 °C
- Initial samples prepared using Mayer rod coating

Quantification of Ionomer Distribution


Kelvin Probe



$$CPD = \phi_S - \phi_{Tip}$$






Mayer rod coated CCDMs





Kelvin probe provides a simple, non-destructive method for screening of surface ionomer content

X-ray Computed Tomography




- XCT verifies Kelvin probe results
- Water/1-propanol ratio influences ionomer distribution

Influence of Surface Ionomer Content







- Increasing surface ionomer content increases:
 - Catalyst activity
 - Fuel cell performance

Gravure-Coated Catalyst Layers




- Coated selected inks based on Mayer rod results
- 1-2 m coated for each condition
- Compared to spray-coated CCDM with ionomer overcoat, R2R-coated CCDMs achieve
 - Same catalytic mass activity
 - 85% of high current density performance

Influence of Solvent on Ionomer Distribution




Conclusion and Future Work

- Increasing surface ionomer content increases catalytic activity and fuel cell performance of R2R-coated CCDMs
- Adjusting the ratio of water and 1-propanol in catalyst ink modifies the distribution of ionomer
- Ongoing work: exploring alcohols with higher boiling points to further control ionomer distribution



Want to work at NREL?

- R3643: Postdoctoral Researcher – Coating Process Science-Fuel Cells and Electrolysis
- <http://www.nrel.gov/careers>
- Come talk to Scott Mauger or Mike Ulsh



Thank you

www.nrel.gov

NREL is a national laboratory of the U.S. Department of Energy, Office of Energy Efficiency and Renewable Energy, operated by the Alliance for Sustainable Energy, LLC.





Materials and Methods

- Catalyst: Pt on high surface area carbon (TKK TEC10E50E)
- Ionomer: Nafion, 1000 EW (Ion Power D2020)
- Membrane: Nafion, 1000 EW, 25 μm (Nafion NR211)
- Diffusion Media: SGL Sigracet 29BC
- Catalyst ink – 3.2 wt% PtHSC
- Ink Dispersion: High shear mixer (Ika Ultra Turrax)
- Gravure Coating
 - 1 m/min
 - Air floatation oven: 80 °C


R2R Coating of Ionomer Gradient Electrodes

Down-selection from rod-coating screening experiment to demonstrate successful R2R coating


- Inks – Coated 2 m each
 - 0.9 I:C, 25 wt% H₂O
 - 0.9 I:C, 75 wt% H₂O
 - 1.2 I:C, 75 wt% H₂O
 - 1.6 I:C, 75 wt% H₂O
- Solvents: water and 1-propanol
- Catalyst: 50 wt% Pt/HSC
 - Loading: 0.1 ± 0.01 for all coatings
- Ionomer: Nafion 1000 EW
- Substrate: SGL 29BC
- Oven Temp: 80 °C
- Web Speed: 1 m/min





Hard X-ray Nanoprobe Beamline at APS



Sample Preparation



Reconstructed Images




Optical Enclosure for X-ray Nanotomography at APS

- Images were taken at 32-ID
- X-ray energies from 3 to 30 keV
- ~ 20 nm pixel size was obtained
- Air bearing stage dampens most of the jittering and helps in aligning projection images at 32-ID
- Large field of view and flexible sample environment for in situ experiments
- Beamline is capable of absorption contrast and Zernike phase contrast imaging


Phase and Absorption Contrast Images

- The samples were Cs⁺ stained to visualize ionomer along with pore morphology


Phase Contrast AMO 1



Phase




Absorption



AMO 4

Absorption Contrast AMO1



- Relies on determination of phase shift of the transmitted X-ray
- It helps for imaging low atomic number materials
- Phase contrast mode shows all the materials above resolution (including Cs⁺, C)
- All the dark regions correspond to the pores (above 20 nm)
- Raw data shows tiny pores and dense electrode

- Resolves based on e- density
- Absorption contrast mode provides contrast of the high atomic number materials
- Absorption intensity is related to Cs⁺ and indicates the presence of ionomer
- Ionomer with sizes below nano-CT resolution can't be visualized
- Bright regions correspond to ionomer agglomerates

