


# Stability of encapsulants using Cu electrode

Naoto Imada, Keisuke Ogawa, Hiroshi Kanno, Hiroshi Inoue, Eiji Maruyama, and Shingo Okamoto  
Solar Business Unit, Eco Solutions Division, SANYO Electric Co., Ltd. Eco Solutions Company of Panasonic Group  
Phone: +81-72-438-9634, e-mail: imada.naoto@jp.panasonic.com

## Motivation

Replacing Ag on a photovoltaic cell with a Cu electrode has attracted increased attention as a way to meet the market need for lowering cost.

However, Cu acts as a catalyst for the thermal-oxidative degradation of polymer.




Therefore, we have compared the various impacts of Cu-catalyzed degradation by testing the discoloration and tensile strength of encapsulants.

## Conclusions

1. Cu acts as a catalyst for the thermal-oxidative degradation of encapsulants.
2. There is a great difference between the lifetimes of Cu-contacting encapsulants.
3. Correlation between discoloration and lifetime is confirmed.

## Discoloration testing of Cu-contacting encapsulants



### (1) High temperature testing

#### Condition

- 120 °C
- 1000 hours
- Ambient air

### (2) Evaluation method

- Reflectivity measurement
- Appearance inspection

Sample	A	B	C	D	E	F
Polymer	EVA	EVA	EVA	PO	PO	PO
Discoloration with Ag <sup>※3</sup>	◎	◎	◎	◎	◎	◎
Discoloration with Cu <sup>※3</sup>	○	△	△	◎	○	○

※3 ◎ : no discoloration ○ : yellow discoloration △ : brown discoloration

■ All Ag-contacting encapsulants do **not** discolor.

■ Most Cu-contacting encapsulants **discolor**.

◆ Cu acts as a catalyst for the thermal-oxidative degradation of encapsulants.

## Tensile strength of Cu-contacting encapsulants and analysis of lifetime by using Arrhenius model

### (1) High temperature testing

#### Condition

- 120 ~ 140 °C
- 1000 hours
- Ambient air

### (2) Tensile strength testing

#### Condition


- Dumbbell shape (JIS K7113-2)
- Room temperature (25 °C)
- 1.4 mm/sec

### (3) Arrhenius analysis


$$L = A \cdot \exp\left(\frac{E_a}{kT}\right)$$

L: Lifetime (the time when the tensile strength decreases to 50% of initial value)  
A: Pre-exponential factor  
E<sub>a</sub>: Activation energy  
K: Boltzmann constant  
T: Temperature


Results of tensile strength testing at 120 °C (dependence on encapsulants)



Results of tensile strength testing for sample B (dependence on temperature)



Results of Arrhenius plot for sample B



- The tensile strength decreases as testing time increases.
- The decrease in tensile strength is different between encapsulants.
- The degradation rate increases as temperature increases.
- Linear correlation is shown between ln(L) and 1/T.

Sample	A	B	C	D	E	F
Polymer	EVA	EVA	EVA	PO	PO	PO
Discoloration	○	△	△	◎	○	○
Lifetime <sup>※4</sup>	○	○	△	◎	◎	◎

※4 ◎: Stable ○: over 50 years △: under 50 years

◆ There is a great difference between lifetimes of the encapsulants.  
◆ Correlation between discoloration and lifetime is confirmed.

### Why does this difference occur?

1. Different polymer structures (EVA, PO, etc.)
2. Different additives : concentrations, types (antioxidant agent, HALS, crosslinking agent, etc.)

## Future plans

1. Compare high temperature testing and outdoor testing (some papers show a non-linear Arrhenius plot for PO degradation).
2. Develop novel method to quantify Cu-catalyzed degradation (yellow Index, transmittance, etc.).
3. Develop high durability encapsulants.